

RouteMEX

SR Concrete Platform Edges

O Gauge

One piece Resin Cast plastic sections which are self supporting on the baseboard and weigh only 66 grms for straight sections and 42 grms for ramps.



Assembly:

File of any moulding flash and do a "Dry Fit" before using adhesive. Check the height by laying some track and using a coach. The platform should be more or less level with the coach running boards (steps). Adjust the height of the track as required. Mark the position of the platform on the baseboard and draw a pencil line. Use epoxy to adhere units together and to the baseboard. Epoxy will allow more time to align sections. Superglue is very effective, BUT, it's rapid drying time will make it more difficult to align sections.

NOTE: White PVA glue *can* be used, but is NOT ADVISED for portable layouts as the adhesion is poor and any flexing of the substrate will cause it to fail.

Painting:

Priming is not essential, but if desired Halfords spray grey primer will give the best results. Enamels will adhere directly to un-primed sections. Water based acrylics can also be used on un-primed sections but do not overthin the paint.

*Contains small parts
Unsuitable for children under 14*

www.routemex.com

